

EnSURE Touch - ATP Hygiene Monitoring



Everything you need. On one screen.

EnSURE Touch's responsive, shatter-proof touchscreen design puts all the functionality and features of Hygiena's ATP Monitoring Systems at your fingertips. In just a few touches you can:

- Run a quick test
- Add and edit users
- Search through plans, locations, and users
- Check the device's calibration
- Run a re-test
- Sync to SureTrend™ Cloud
- Change screen and battery settings
- Connect to Wi-Fi
- Share your screen with Hygiena Technical Support
- View trend analysis and reports
- Display results in competitor RLU limits



Add more data to your results

Advanced settings allow EnSURE Touch users to add valuable data such as room number, cleaning personnel, and cleaning products used to each test run on the device. Providing greater insight when evaluating processes, performance, and personnel.

Removable read chamber makes cleaning easy.

One of the unique design features of EnSURE Touch is the ability to remove the read chamber if contamination enters the reading area. Hygiena instruments are some of the only systems that have this important design feature. With all luminometers, if used correctly, no contamination should enter the read chamber. However, user error and the environment in which systems are used makes a contaminated read chamber common.



Other manufacturers require you to ship your system back if the read chamber becomes contaminated. This results in costly repairs and delays your testing until the machine is returned. Hygiena systems are designed so you can clean the read chamber yourself so downtime is minimized and costs are averted.

Tough outer shell.

EnSURE Touch's durable outer shell and 5" shatter-proof screen are meant to last. The shatter-proof screen resists scratches and the robust outer shell is sturdy to withstand the shock of minor drops and years of use.



EnSURE Touch - ATP Hygiene Monitoring



Smart battery management features.



EnSURE Touch runs on a re-chargeable Lithium-Ion battery pack that offers long battery life and rapid charging via USB-C. EnSURE Touch also features smart battery management features like screen brightness adjustment, screen and device timeout, and daily shut down options, all geared towards maximizing your time testing, and limiting your time charging.

Designed for one handed use.

Even when you already have your hands full, the sleek design of the EnSURE Touch makes scrolling and selecting test locations a breeze. The EnSURE Touch is operable with one hand, making your life that much easier.

Wi-Fi Capabilities



New Suretrend CLOUD available with the EnSure Touch

The New Suretrend CLOUD offers multi-site companies the ability to communicate data to a central location

